



Mini Coop 2 Assembly Manual



HORIZON STRUCTURES MINI COOP KIT CONTENTS

Skid Contents:



Plywood Roof Sheathing – 2 pieces



Floor with Nest Box Dividers
NOTE: Glasbord flooring attached



Front Wall Panel



Back Wall Panel



Right Wall Panel



Left Wall Panel



Drip Edge - metal
Top & Bottom (or Front & Back): shorter
Side Pieces: longer



Corner Trim – wood
Back Wall: shorter
Front Wall: longer



3 Nest Dividers



1. Nest Box Sill
2. Roost Bar
3. Roof Rafter
4. Soffit
5. Front & Back Face Plate



Paint & Brush: Touch-up Siding & Trim
3 Bags of Screws



Shingles – 3 Bundles
Short: 1,2, & 8
Long: 3-6, 9-11
Starters & Top Cappers



Longer = walls (inside and out) and legs
Shorter = everything else.



Drip Edge and Shingles

Assembly Instructions: *When your kit arrives, unpack the pallet, inspect the components and make sure nothing is missing.*

LEGS & BASE:



- The pressure treated coop legs are attached to the bottom of the shipping pallet (which is also the coop floor).
- Unscrew the legs from the floor to remove them.



- Reposition the legs under the floor as shown.
- Screw each leg tightly into each corner using the long screws.
- Use 4 screws per leg – 2 on each side of the leg where it touches the base edging.



- Each leg gets 2 braces.
- Attach the braces to the legs and coop base as shown.



- Attach the 2 pressure treated leg supports to the legs as shown.
- These span the legs on the right and left sides of the coop.
- Use 6 long screws for each leg (2 screws, evenly spaced, on 3 sides of each leg: outside, top and inside)
- Screws go in at an angle as shown.



- You are now ready to add the walls to your coop!

All Chicken Coop kits will come with full assembly instructions